
CON-TACT LINER

CREATIVE COVERINGS

Self Adhesive

SURFACE PREPARATION

Clean surfaces prior to application as necessary
All surfaces should be dry, clean, and smooth

APPLICATION

Measure area to be covered
Carefully cut to fit using the lines on the backing paper as a guide
Leave approximately 1/8" overlap on all edges for probable shrinkage over time
Start at a corner and peel off the backing paper to apply
Smooth from center out to help eliminate bubbles of air

CLEANING AND MAINTENANCE

Clean by simply wiping the surface with a damp cloth and mild soap if necessary

