



U-Shaped Door Bottom

Installation:

INSTALLS ON OUTSIDE OF DOOR

- 1. Measure width of door.**
- 2. Shorten bottom and insert if needed.**
- 3. Slide or press the vinyl insert into the channel on door bottom.**
- 4. Slide on door so the insert rests on the threshold. Make sure screw holes are on the outside.**
- 5. Mark hole locations, then drill and screw into place.**

Instalación:

SE INSTALA EN EL EXTERIOR DE LA PUERTA

- 1. Mida el ancho de la puerta.**
- 2. Corte el fondo y la inserción de vinilo si es necesario.**
- 3. Deslice o presione la inserción de vinilo en el canal del fondo para la puerta.**
- 4. Deslice en la puerta de manera que la inserción descance sobre el umbral. Asegúrese que los agujeros queden en la parte exterior.**
- 5. Marque los agujeros ,taladre y atornille en su lugar.**

Thermwell Products Co., Inc.
Mahwah NJ 07430 Sparks NV 89431

Need help or information
about any Frost King product?

Call 1-877-FROST 20
3 7 6 7 8



Follow Us @FrostKing