

Tools & Supplies needed:



Prepping the pipe:

VERY IMPORTANT: These are all authentic malleable iron and require necessary cleaning and prepping; do not skip this step.

1. Use gloves to protect your hands. Clean all parts with the wipes and immediately dry with lint-free rag.
2. Use a lint-free rag to apply metal polish to the parts.
3. Allow the metal polish to dry and then buff to clean.