

How to Install Corner Guard (Outside Corner) Moulding

Corner Guards, Outside Corner and Wall Guard Protectors are defensive corner mouldings for your walls and wallpaper! Protect exposed 90 degree wall corners with decorative Corner Guards

Things You'll Need

-
- Molding pieces
 - Miter saw
 - Coping saw
 - Finish Nails
 - Drill

Instructions

1. Measure the length/ height of the 90 degree corner you want to cover.
2. Cut the outside corner guard moulding to your measured length.
3. Drill pilot holes through the moulding, so the nails won't split the wood when installing.
4. Hold the moulding in place on the corner to be covered. Using the finish nails, nail through the pilot holes into the wall studs, to complete installation