



*Manufacturers* Advanced Composite Materials, Automotive and Apparel  
Specialty Fabrics, Bias Binding, Electrical Insulation,  
Narrow Fabrics, P.V.C. Film, Construction, Survey & Safety Accessories

## **MUTUAL INDUSTRIES INC.**

707 W. GRANGE STREET, PHILADELPHIA, PA 19120

800 523-0888

215 927-6000

FAX: 215 927-3388

CUSTOMER SERVICE LINE

### Instructions for Privacy Fence Assembly

Items you will need for installation:

- Mutual Industries Nylon Locking Ties or similar Zip Ties  
Or use Mutual Hog Rings and Hog Ring Pliers to attach the fence
- A ladder that will reach the top of the fence

Wait for a day without much wind to install the Privacy Fence.

Begin by laying out the privacy fence alongside the fence you will be securing it to.

Working from one end, use a Locking Tie or Hog Ring through the top corner grommet to attach the privacy net to the corner of the fence at the desired height. Making sure to keep the edge straight, secure the other grommets down along the starting end of the fence with additional Locking Ties or Hog Rings. Now, stretching out the fabric as you go to keep it level and wrinkle-free, use Locking Ties or Hog Rings along the top edge to secure each grommet to the fence.

If the privacy screening is tight and without wrinkles, work down along the end to the bottom grommet to secure that end. Then working from one end, stretch the fabric taut from top to bottom and secure the bottom edge with Locking Ties or Hog Rings through the grommets.