

Installation

1. Plug modular end into the wall jack and use the other end of cord to connect phone line devices (phones, fax machine, modem, etc.)

