

# ProFlex™ No-Dig Landscape Edging

## Installation Guidelines

ProFlex No-Dig Landscape Edging is a fast, affordable and easy way to define your landscape and garden areas without the mess and hassle of digging. Proudly made in the U.S.A. from recycled materials, ProFlex is flexible, durable, and versatile enough for many landscape projects.

- 1** No digging required. Using a spade or shovel, clear area where edging is to be placed of turf and debris. Place edging on cleared surface with the anchoring tabs facing toward the planting bed.
- 2** Hammer the included anchoring spikes through the tabs to hold the edging in place. The maximum spacing of the spikes is every 4 ft. If you desire additional anchoring, spike packs are available separately.
- 3** When joining two pieces of ProFlex Edging, use the included overlapping connector. It is designed to overlay on the top of the end tab of each piece, so that when spiked, it minimizes the gap between two pieces of edging. Make sure you cut at the midpoint between the anchoring tabs for best results. Cut edging with hand snips or a fine tooth saw. Always take proper safety precautions when spiking and cutting edging.
- 4** Backfill to the top of the edging with mulch or other groundcover.

