

EASY INSTALLATION

Follow each of the numbered steps below
(Flat head screw driver required)

3

Attach
Rubber Boot
to Y Connector
and Discharge
Line

4

IMPORTANT:
Check all
connections and
**TIGHTEN
ALL CLAMPS**

2

Place
Y Connector
into Threaded
Check Valves

1

Screw
Threaded
Check Valves
into
Pump 1 and
Pump 2

