

B H F

Window Curtain Panel Installation Guide

1. Remove panel(s) from package
 2. Use iron on low heat to straighten and remove creases/wrinkles from packaging
 3. Hang curtain panel(s) on window hardware
- o GROMMET – Feed rod through metal rings
 - o ROD POCKET – Feed rod through rod pocket opening at top of panel
 - o BACK TAB – Feed rod through tabs on back of curtain panel
 - o TABTOP – Feed rod through tabs on top of curtain panel
 - o TIETOP – Tie tietops around rod

For Window Measuring

Width	Up to 29"	30"-39"	40"-48"	49"-72"	73"-96"	97"-120"	121"-144"
You will need	1 Panel	1 Panel	1-2 Panel	2-3 Panel	2-3 Panel	3-4 Panel	4-5 Panel

- Hardware will generally extend 4 in. beyond the window frame. (2" inches on either side)
- For a full look, plan on two to four times the fabric width to the width of your window.
- Panels are usually hung 4 in. above the window frame.
- Shorter panels are meant to hang 4 in. below the window sill.
- Typically you will want to use an even number of panels per window.