



NOT JUST A PRODUCT...A SOLUTION.
EKENAMILLWORK.COM

Panel Moulding & Chair Rail Installation Instructions

Tools & Materials Needed

- Caulking gun
- Latex Caulk
- Sponge or Clean Cloth
- Miter Saw
- Polyurethane construction adhesive [PL Premium® recommended]
- Finishing Nails

Prior to Installation

1. It is recommended to finish moulding before installation. If painting, use an exterior grade acrylic latex or oil based paint.
2. Place moulding in room 2 to 3 days prior to installation. This allows the moulding to adjust to the temperature of the room.
3. Clean the installation surface with a sponge or clean cloth.
4. Make sure that the installation surface is dry before proceeding.

Installation

1. Apply a continuous 1/4" bead of construction adhesive along the back of moulding lengths. Press moulding into desired place. Use finishing nails to secure moulding into place.
2. Apply caulk in remaining gaps and smooth with finger or putty knife. Caulk can be used to fill in holes left from finishing nails.
3. Touch-up moulding as needed.