

## WOODWORKING ASSEMBLY

### Materials needed:

- 1 - Table Top
- 4 - Table Legs
- 4 - Corner Plates
- 1 - Bag of Skirt Fasteners

### Tools needed:

- Drill, 5/32 in. Drill Bit, Phillips Head Screwdriver, 1/2 in. Wrench, Sandpaper, Miter Box & Saw, Square

- Use furniture legs with top square



- Use corner plate hardware (screws are included)



### 1 Choose a table top.

2761



Oval Table Tops



Square & Rectangular Table Tops



Round Table Tops

### 2 Mark desired position for table legs and measure skirting to fit.



### 3 Cut the skirts to length and cut a 1/4 in. deep slot 1 in. from each end of the skirts. (use skirting material of your choice - recommended 3/4 in. thick x 1-3/4 in. tall)

### 4 Place the flat ends of the skirts down and assemble using the corner plate.



### 5 Mark and drill 9/32 in. hole on chamfer edge (flat corner side) of table leg and insert hanger bolt.



### 6 Place each leg into skirt assembly and affix to table top using skirt fasteners.



### 7 Ready for finishing.



## QUICK MOUNT ASSEMBLY

### Materials needed:

- 1 - Table Top
- 4 - Table Legs
- 4 - Surface Mounting Plates

### Tools needed:

- Phillips Head Screwdriver, Square

- Use furniture legs with hanger bolt



- Use surface mounting plates (screws are included)

### 1 Choose a table top.



Oval Table Tops



Square & Rectangular Table Tops



Round Table Tops

### 2 Choose mounting plate.



2751



2752



2755

### 3 Mark the underside of the top for the leg mounting plate locations and apply using screws included.



### 5 Ready for finishing.



### 4 Attach leg to plate.



# Table Leg Assembly Instructions

- Woodworking Assembly
- Quick Mount Assembly



## Waddell Manufacturing Company

3688 Wyoga Lake Road • Stow, Ohio 44224 • P: 800.433.1737  
www.waddellmfg.com • sales@waddellmfg.com