



## BLACK TIE GRID ASSEMBLY INSTRUCTIONS

- STEP 1** There are 2 pcs of each: panel B and panel A. Put panel B and panel A together by fully inserting legs of panel B into the brackets of panel A, then tighten the three screws. Repeat this step, then you will get one front grid and one rear grid.
- STEP 2** Place left and right bottom spacers C & D on floor (please note differences between the front and rear of left and right bottom spacers - the front groove is higher than the rear groove.).
- STEP 3** Place rear grid (B+A) in rear grooves of left and right bottom spacers with vertical bars positioned in grooves as illustrated.
- STEP 4** Place front grid (B+A) in front grooves of left and right bottom spacers with horizontal bars positioned in grooves. Make sure both vertical extensions bars are positioned in holes of front bottom spacers.
- STEP 5** Press grooves of brackets E, G & F over horizontal bars of front and rear grids as illustrated.
- STEP 6** Move the grid and bottom spacers against wall until the rear of brackets touch the wall. Mark wall with pencil through screw hole in rear of bracket. Drill holes where marked and insert anchors. Secure racks to wall with screws. Then tighten the screws through brackets E & F to the wall.

