

Installation Guide  
CP-234

Directions:

1. Use a wire brush, chisel or similar tool to remove all loose material, dust, dirt, oil and grease from the area to be repaired. Use a solvent to remove oil and grease.
2. Rough up the surface one or two inches beyond the area to be repaired for a good bond.
3. Dampen the area to be repaired. Do not flood.
4. Apply mastic as it comes with flexible putty knife. Smooth and feather edge.

As glue:

Apply at least 1/8" to both surfaces to be bonded. Push together, but be sure at least 1/8" remains between surfaces for proper bonding. Do not apply if rain is likely within period or if temperature will drop below 40°F. Keep from freezing.