



**Commercial
Electric™**

Item #187 635 / 187 668

188 295 / 190 242

189 285

Model #XXXXXX

Use and Care Guide
Wall Phone Plate

Installation

1. Remove the old wall plate from the wall outlet box.
2. If necessary, strip about ½ in. of insulation off of each wire.
3. Attach the four color coded wires from the phone line cord to the corresponding color wire terminals on the back of the new wall jack. For example, connect green to green, yellow to yellow, red to red, and black to black. Retighten the screws (1) to secure the wire connections together.
4. Attach the wall plate to the wall using the two screws (AA) located on the back of the wall plate.

