



How To Replace Screening

Tools & Materials Required:

- Screening at least 2" (5 cm) wider than screen frame
- Screen tool
- New spline
- Utility knife



1. Lay screening over frame on flat surface, overlapping spline groove at least 1" on all four sides.



2. Using concave end of screen tool, insert spline at one corner and roll into groove over screening. Place hand on screen surface to hold screen straight. Roll spline into groove on all four sides.



3. Trim off excess screening with utility knife on outside edge of the spline groove.

Choose the Right Screen for the Job

Saint-Gobain ADFORS offers a variety of specialty screen types to meet any need.



Clear Advantage

Nearly invisible screen allows more light and enhances curb appeal



Extra Strength

Extend the life of your screen



Pet Resistant

Withstands damage from household pets



Small Insect

Greater protection from tiny insects



Sun Guard

Controls the damaging effects of the sun

Also Available

- Standard Aluminum
- Standard Fiberglass

Visit www.adfors.com to learn more about our products, view our how-to videos and use our screen selector tool to make sure you have the right screen for your needs.

SAINT-GOBAIN ADFORS America, Inc.
1795 Baseline Road
Grand Island, NY 14072 - USA
Phone: 800-762-6694
Fax: 716-775-3902

www.adfors.com

Follow us on:

