



*Manufacturers* Advanced Composite Materials, Automotive and Apparel  
Specialty Fabrics, Bias Binding, Electrical Insulation,  
Narrow Fabrics, P.V.C. Film, Construction, Survey & Safety Accessories

## **MUTUAL INDUSTRIES INC.**

707 W. GRANGE STREET, PHILADELPHIA, PA 19120

800 523-0888

215 927-6000

FAX: 215 927-3388

CUSTOMER SERVICE LINE

### **WF200 Polypropylene Black Woven Stabilization Barrier**

#### Suggested Installation Instructions:

1. Prepare the install area. Remove any brush from the top layer of soil. Fill in any open holes with fill.
2. Smooth and level the subgrade. The area should be flat before continuing.
3. Place geotextile in the installation area. The barrier should be stretched as tight and as flat as possible.
4. When using more than one roll, overlap adjacent rolls a minimum of 12 inches.
5. Secure the fabric in place with staples or pins. Barrier should be secured along the edges and then along any overlapping portions.
6. Loosely place fill directly on the geotextile.