

All-Weather Door INSTALLATION INSTRUCTIONS

Tools Required for Installation

Hammer and Awl (or Nail) • Drill and $\frac{3}{8}$ " (1cm) Drill Bit • Sabre Saw • Phillips Screwdriver • Wear Safety Goggles

- Determine template placement** - The die-cut template is located in the center of pet door (in box). Remove screws holding the frame together; lift out template. Center template (width) in middle of door; tape in place. Position the top of the template 2" (5.1cm) taller than your pet's shoulder.
Important: Under no circumstances should the bottom edge of the rough opening be less than 3" (7.6cm) from the bottom edge of the wood door.
- Outline pet door opening** - With template taped in place, use a pencil to draw around the inside edge of template onto door. Use a nail or awl to mark outer screw holes.
- Drilling holes - Next:** Drill the four (4) $\frac{3}{8}$ " (1cm) diameter outer screw holes.
- Cutting the opening** - Mark and drill four (4) $\frac{3}{8}$ " (1cm) diameter inside saw-out starter holes. Begin with one of the inside $\frac{3}{8}$ " (1cm) corner holes. Using a sabre saw, cut along inside edge pencil line.
- Assembly and adjustments (see diagram)** - Insert outer frame (A) into opening from exterior side (frame must be flush with door surface). Place inner frame (B) into opening from inside door and hold in place. Install screws (C) and tighten until snug. **Do not over-tighten.**
- Locking your pet door** - Slide self-locking cover (D) into guide channel.

All Weather Dog Door Wall Installation Kit - The All Weather Door can also be installed in walls $4\frac{3}{4}$ " - $7\frac{1}{4}$ " (12.1cm - 18.4cm) using the optional Wall Installation Kit available from your retailer.

As with any home improvement project, if you do not have the tools or skills to properly install your pet door, we suggest using a professional handyman or licensed contractor.

