

PRE-DRILLED UNITS -PALLET SHELF

HANGING INSTRUCTIONS



STEP 1

Insert the supplied #6 2.5" phillips head screw into the pre-drilled hole*. Do so until about 1/8" of the screw exits the back side of board. At desired height hold the shelf level and press the screw tip into the wall surface making an indentation.



*the 9/64 pre-drilled holes are halfway down and are 16" apart

STEP 2

At the mark from the screw tip, either on a stud or using the supplied drywall anchor tighten screw until secure (do not over tighten).



Have Fun Decorating!

