

# Vigoro 20 ft. /60ft. Plastic Lawn Edging Instructions

The label attached to your Vigoro Edging does not need to be removed for installation. If installed correctly, the label should not be visible.



**Step 1**

Unravel the coiled edging and place a source of weight to keep down both ends of the edging. Only lay uncoiled edging on pavement and not on grass. If the temperature is below 65 degrees in direct sun, the edging will need to be exposed to the sun for a minimum of two days. If it is between 65-75 degrees in direct sun, 8 hours. In excess of 75 degrees in direct sun, three to four hours will be sufficient.

**NOTE:** This method will allow for EASIER installation as the goal is to install the edging as a flat versus a coiled piece. Installing the product right from the packaging will create misery in installing the edging and affect the ability for the edging to stay in the ground.



**Step 2**

Dig a 4 inch trench along lawn edge



### Step 3

Sink edging into trench with the bottom “V” lip facing the rocks or mulch



### Step 4

Sink stake through the side wall of edging every 4 feet at a 45 degree angle

Stakes Sold Separately

Metal Stakes MSD-50



Poly Stakes PS-R12

