

## **GREAT STUFF Pestblock Insulating Foam Sealant**

1. Wear Gloves and Protective Eyewear
2. Eliminate all sources of ignition. Ensure good ventilation
3. Shake vigorously – minimum 30 seconds
4. Screw straw assembly onto valve. Dispense SLOWLY



5. Fill voids <50%. Mist water to speed cure