



APPLICATION GUIDE

CANDY KILLER CAN

How to Apply (Application Steps)

- 1 Candies are applied over an existing base coat color, with Silver and metallic s being the most popular choice. Such as our Nevada Silver Stylin' Base Coat. (Part number KC-ASB-02) If your piece is already base coated, you can proceed to step number 12.
- 2 Always apply paints in a well ventilated area, and wear a NIOSH approved respirator to avoid breathing any fumes.
- 3 Prepare and prime your part first. Epoxy primers are best for bare metal, and primer surfacers are best for plastics, fiberglass, or wood. Some plastics may require an adhesion promoter but most plastics, like ABS plastic, are fine without adhesion promoters.
- 4 Before applying your primer, remove all dirt, grease, oil, salt, and chemical contaminants, by washing the surface with a commercial detergent, or other suitable cleaning method.
- 5 Rinse with fresh water and allow to completely dry.
- 6 Remove any existing loose paint, or rust, etc, with a wire brush or sand paper.
- 7 Lightly sand glossy surfaces to create a surface profile for adhesion.
- 8 Apply your primer to the surface according to the manufacturers specifications for you particular primer.
- 9 Let your primer cure according to the manufacturers specifications for your particular primer, and then lightly scuff that to create a surface profile for adhesion.
- 10 Apply your base coat color over the primer according to the manufacturers specifications for your particular base coat, using steady even passes, until you achieve coverage.
- 11 Let your base coat cure according to the manufacturers specification for your base coat, and then lightly scuff that to create a surface profile for adhesion.
- 12 You are now ready to begin applying the candy coloring over your base coat. Begin making passes over the surface from about 6-8 inches away, and observe to color as you do.
- 13 The more coats of candy color you apply, the DARKER you color will be.
- 14 One the desired color tone is achieved, STOP, and let the candy color flash (dry to the touch) for about 15-20 minutes, and then top coat with a good quality clear coat, for durability and a super deep wet look
- 15 For truly one of a kind colors.....Other color candies can be applied OVER existing candy colors, to create custom colors, and unique color tones.

