

Door Mirror Installation Instructions

Directions work on hollow and solid doors.

Step 1:

- Hold the mirror up on the wall near eye level, or exactly where you'd like it placed.
- Tip: If the mirror is too large or heavy to hold, have a second person assist or use a carpenter's level or laser level instead.

Step 2:

- Mark the wall at the center of the top of the mirror with either a pencil or piece of painter's tape. This is the wall mark.

Step 3:

- On the back of the mirror, measure the distance between the two D rings. This is the hook spacing. Now measure the distance from the top of the frame to the top of one D ring where it will be hung on the hook. This is the adjustment measurement.

Step 4:

- On the wall, measure the adjustment measurement down from the wall mark. This is the center point of your hook spacing. Mark the end points of your hook spacing, keeping the center point mark centered. The two end points are where to hang the hooks on the wall

Step 5:

- Hammer the hook(s) into the wall. It is always best to hammer into a stud on the wall, but your mirror will be safely secured in drywall or hollow core door, as long as you use the number of hooks included with your mirror. To be extra secure, you can use drywall anchors instead of the hooks provided if desired.

Step 6:

- Place mirror's D rings on hook(s) and straighten.