

Master Garden Products.

1-800-574-7248

Fence Assembly

Note: This is only our suggested method of putting up the fence panels. You may do it in any way you want. This is just a suggestion to help.

1. Unpack your Fence Panels. Make sure you have received the correct panels. **Note: For this method you will need hardware that is NOT included. We suggest getting 6” Bolts with a nut and washer from any hardware store. The amount needed varies on how many panels you bought. We suggest 6 per panel.**
2. Also you will need 4 inch x 4 inch x 8 foot pressure treated wood posts. These will support the fence. Bury them 18 inches into the ground. Again the amount needed varies, you'll need 2 per panel buried 6 feet apart from each other.
3. Now that you have the posts up you can lean the fence panel against the posts. You'll want the end of the fence panel in the middle of each post, so that you have room for more panels to be attached. We suggest something like this:



4. As you can see the panel is in the middle of that post. Now you will need to pre drill 3 holes through the bamboo and out the back of the post. One at the top, middle, and bottom. Be sure to have a bit long enough to go through that distance, it is less than 5 inches. Also the bit needs to be the same diameter as the bolts you got.

5. Once you do that you can install the bolts through the fence panel and out the post.



6. Repeat the same on the other side and with any other panels you bought.
7. Again this is just our suggestion. So if you followed this it is done and looking good!

Thank you for your business!

Any Questions? Call us at:

1-800-574-7248