

8 SIMPLE STEPS

to resurface asphalt like a pro

T-MAT™
ASPHALT RESURFACER

Read all instructions and warning before using product.

Instructions for use:

1. For best results, fill any cracks or potholes prior to installation of T-MAT
2. Clean pavement surface of debris or vegetation.
3. Thoroughly mix product. Drill and paint mixers will provide the best mix.
4. Start at the highest point and work your way down.
5. Apply with a squeegee using a back and forth motion, overlapping the previous pull by 70%.
6. Block or cone off area to prevent traffic on the wet surface.
7. Stay off until completely dry (2-4 hours). Keep car traffic off for at least 12 hours, however 24 hours is recommended.
8. Temperature must be 60°F or rising for a 24 hour period after installation. Do not install if rain is imminent. High humidity can increase dry times.



SAFETY WARNING



- **Always wear safety goggles and protective clothing to avoid contact when installing product.**
- **Pail is heavy.** Always lift with 2 hands.
- **Keep product away from children at all times.** Product should be stored with top of pail in place and out of reach of children. Store in area that is at least 50° F.
- **Do not inhale or ingest product.** If inhalation or ingestion occurs, seek medical attention. For contact with skin, wash with warm water. If skin irritation occurs, call a physician. For contact with eyes, flush with warm water for at least 15 minutes. Call a physician.

Go to www.CRIUSCORP.net for more detailed safety and installation information.

ORDER MORE AT
www.CRIUSCORP.net



601 Carlson Parkway, Suite 900
Minnetonka, MN 55305
1-877-251-8295

