



GARAGE THRESHOLD INSTALLATION INSTRUCTIONS

- 1) Position threshold under door and mark lines with a pencil
- 2) Apply polyurethane adhesive to concrete
- 3) Apply threshold to concrete, lower door and let adhesive cure for 24 hours

