

Whether you're working with indoor or outdoor applications, crossheads are an excellent design improvement to the outer casings of doorways and windows. Manufactured from high density polyurethane, our crossheads carry a limited lifetime warranty against rotting, splitting, or cracking. Our crossheads can be trimmed with standard woodworking tools and installed using construction adhesive.

Tools & Materials Needed

- Caulking gun
- Elastomeric adhesive caulk
- Tape measure
- Sponge or clean cloth
- Putty knife
- Extra fine sandpaper

- Hammer
- Corrosion-resistant finishing nails or screws
- Jigsaw, keyhole saw, or pen-knife
- Pencil
- Handsaw

Prior to Installation

- It is highly recommended that you paint/finish our crossheads before you install them. Once installed, you can apply any necessary touch-up paint/finish.
- Clean installation surface and back of crosshead of all dirt and dust with a clean cloth or sponge.
- Make sure that the surface and the back of the crosshead are completely dry before attempting installation.

Important Safety Instructions

- Make sure to use the correct tools recommended.
- Wear safety goggles.
- Follow fixture, power tools, and paint manufacturers' instructions and users manuals.
- Use common sense and follow good construction practices.

Installation Process

- 1. Place the crosshead on top of the entrance opening.
- 2. Align crosshead with the outer edges of the opening or pilasters. (Note: The crosshead can be slightly larger than the opening as long as the overhang is equal on both sides.)
- 3. Fasten the crosshead using PL Premium Construction Adhesive and any necessary fasteners.