

Manufacturers Advanced Composite Materials, Automotive and Apparel Specialty Fabrics, Bias Binding, Electrical Insulation, Narrow Fabrics, P.V.C. Film, Construction, Survey & Safety Accessories

## **MUTUAL INDUSTRIES INC.**

707 W. GRANGE STREET, PHILADELPHIA, PA 19120

800 523-0888

215 927-6000

FAX: 215 927-3388

CUSTOMER SERVICE LINE

## 4 'X 225' JUTE MESH BLANKET

Suggested Installation Instructions:

- 1. Dig an 8 inch trench at the top of the slope, insert the top of the roll then backfill the trench over the blanket edge.
- 2. Unroll the blanket down the slope of the hill. Use sod staples to hold the blanket in place every 12 inches.
- 3. Over-lap the blankets 4" going down the slope.