

Window Panel Installation

1. Prepare curtain rod to receive window panel by unscrewing one or both of the curtain rod finials.
2. Remove window panel(s) from packaging.
3. Feed curtain rod through window panel header.
 - a. On Grommet panels, feed rod through metal rings.
 - b. On Pole Top or Rod Pocket panels, feed rod through the side with the larger opening.
 - c. On Back Tab panels, feed rod through tabs.