

872.241.0016
Toledo, Ohio
sales@renesinks.com
renesinks.com

TOPMOUNT SINKS

Installation/ Mounting Guide

THE INSTALLATION OF ANY TOPMOUNT-STYLE SINK

Topmount stainless steel sinks are designed to be mounted over the countertop.

In addition to silicone caulking, various styles of clips are used to further secure sinks to the counter.





872.241.0016
Toledo, Ohio
sales@renesinks.com
renesinks.com

TOPMOUNT SINKS

Installation



STAINLESS STEEL TOPMOUNT CLIP (US Series)

Shown here is an illustration of the clip style and how it attaches when installing a René topmount stainless steel sink.

THE STEPS

- Using the template provided with your purchase, measure and cut the hole in the countertop.
- Determine the locations for the clip brackets around the perimeter of the sink. Pre-drill holes for the clips using appropriate methods for the countertop material.
- With denatured alcohol, clean the area where the surface of the sink will meet the countertop.
- Evenly apply a bead of silicone along perimeter edge of the opening on the top of the counter.
- Carefully align the sink over the countertop opening and lower into position, applying pressure to secure a seal of the silicone against the countertop.
- Re-check that the sink is evenly aligned with the countertop.
- Attach and tighten the clip brackets against the edge of the sink. Do not tighten one screw completely before the others.

- To begin, partially tighten one clip. Then, tighten the clip directly across from it, and so on, until all clips are fully tightened.

 This will safeguard against an uneven or insecure installation.
- With denatured alcohol and a cloth, wipe along the perimeter of the sink and countertop to remove any excess sealant.

