

Push Broom & Squeegee Description: Assembly Instructions

NOTE: Be sure that you have all of the parts before you start to assemble.


PUSH BROOM ASSEMBLY

- Align the Broom Handle (B) connector with the grooves in the Broom Head (A)
- Securely tighten the Broom Handle to the Broom Block using Bolt (C).
- Loosely assemble Left Broom Brace (F) and Right Broom Brace (G) using Bolts (E). Do not tighten all the way.
- Slide the Broom to the Broom Head using Screws (D) and tighten.
- Finish tightening Bolts (E).

Part	Description	QTY.
Α	Broom Head	1
В	Broom Handle	1
С	Bolt, 5/16" – 18 x 1-1/4"	1
D	Screw, 1/4" – 10 x 7/8"	2
E	Carriage Bolt, 1/4" – 20 x 1"	2
F	Left Broom Brace	1
G	Right Broom Brace	1

REQUIRED TOOLS 1/2" OPEN END WRENCH 7/16" OPEN END WRENCH

Loosely assemble Attach handle **Broom Brace**



Attach Broom Brace

Assembled Broom



SQUEEGEE ASSEMBLY

- Place the Handle (B) in the center section of the Squeegee Head (A). Attach the Handle using 2 Bolts (G).
- Loosely assemble Left Squeegee Brace (E) and Right Squeegee Brace (F) using Bolts (C). Do not tighten all the way.
- Slide the Squeegee Brace down the Handle and place the Brace in the angled slots. Attach the Brace to the Squeegee Head using 2 Bolts (G).
- Finish tightening Bolts (C).

Part	Description	QTY.
Α	Squeegee Head	1
В	Squeegee Handle	1
С	Bolt, 1/4" – 20 x 1"	2
D	Left Squeegee Brace	1
E	Right Squeegee Brace	1
F	Bolt, 1/4" – 10 x 1.25"	4

REQUIRED TOOLS 7/16" OPEN END WRENCH

Attach Handle Squeegee Brace

