

## STEP ONE

### Assemble the Side Panels

**NOTE:** There are locking tabs located at the ends of the horizontal rails. Once inserted and pushed into the routed holes, they will lock into place.

**1**

Layout the horizontal bottom rail and insert the two long vertical spindles. Ensure the routed holes on the spindles are orientated correctly to eventually receive diamonds (see Figure 1). **The spindles are identified inside the notch at the top with either the letter L for Left or R for Right.**

**2**

Install the arched top rail over the ends of the vertical spindles ensuring the architectural detail faces out (same as bottom rail).

**3**

Insert the four horizontal spindles ensuring that the routed holes on the spindles are **positioned to accept the diamonds** (see Figure 2).

**4**

Pressure fit the diamonds into the square area designated by tensioning into the horizontal and vertical routed holes (four points of contact).

**5**

Set out one post and complete the side panel by inserting it into the post. **Start with the bent top rail first.**

**6**

Lay out the second post with holes facing upwards and insert the completed panel and connected post.

**7**

Flip the trellis over and install screws into the two pre-drilled holes per post. This will lock the horizontal rails into the vertical posts.

