



Goof Proof Water Proofing Membrane Installation

Goof Proof Water Proofing Membrane and seam tape is installed using a modified thin set using a 1/4" x 3/16" (6 mm x 5 mm) V-notched trowel (recommended).

Inside, outside corners, Flexible Pipe Collar, Mixing Valve Seal are installed using the same modified thin set or GP2000 Sealant(recommended)

Once the Goof Proof Water Proofing Membrane, including seams, corners and protrusions have been completely bonded and, therefore, waterproofed, the assembly is ready to be tiled. A water test may be performed before setting tile to verify a successful waterproofing installation. This evaluation may be required by building code officials and is considered best practice. Wait 24 hours after the membrane installation is complete to allow for the final set of the mortar and to ensure waterproof performance of the assembly at seams and connections before water testing.