

C
A
L
I
F
O
R
N
I
A

G
R
O
W
N

Handling & Installation Guidelines

■ **Job Storage:**

Material should be protected from rain and moisture before installation. Store in garage or under loosely applied waterproof tarps.

■ **Cutting Material:**

Apply a 100% acrylic primer to ends after field cuts.

■ **Flash Horizontal Edges:**

Use flashing or horizontal edges so water does not accumulate on edge.

■ **Fasteners:**

Use quality hot-dipped galvanized or stainless steel fasteners for ultimate-long term performance.

■ **Top Coat:**

Apply two coats of a quality brand exterior 100% acrylic topcoat within 60 days of installation.

IMPORTANT NOTE: If trim or siding gets wet before application of top coat, allow to dry out thoroughly before attempting to paint.



Now Available at The Home Depot Stores



PRIMEPINE
SIDING & TRIM

**Please see the Pro-Desk for
special order details.**



You can do it. We can help.



California Grown

Improving Our Environment

Improving Our Economy