

Gap Gone Measurement Guide

Gap Gone Sides Measurement Guide

1. Place the end of a tape measure to the top of the inside window frame



2. Measure from the top of the inside of the window frame to the bottom of the windowsill.

Gap Gone Valance Measurement Guide

1. Measure left to right from the end of the Gap Gone side across the top of the window blinds

