

WALK MAKER® FORMS

PRODUCT No. 6921

PRODUCT DESCRIPTION

QUIKRETE® Walk Maker® Building Forms are reusable plastic molds for creating patterned walks, paths, patios, courtyards, etc.

PRODUCT USE

QUIKRETE® Walk Maker® Building Forms are reusable plastic molds used for forming concrete for pathways and patios. Available in Country Stone, Running Bond Brick, European Block and Basket Weave Brick patterns.

SIZES

• QUIKRETE® Walk Maker® Building Forms are nominally 2' x 2' x 2" (0.6 m x 0.6 m x 51 mm)

INSTALLATION

SURFACE PREPARATION

The Walk Maker® can be placed on any relatively flat surface. It will automatically configure the concrete to the existing base. For professional results, remove one inch of topsoil, and level Walk Maker® before filling with concrete. Removed topsoil can be utilized to fill in open spaces on sides and between concrete after walk has set up.

MIXING

Add 2.5 quarts (2.4 L) of water to each 80-lb. (36.3 kg) bag or 2 quarts (1.9 L) of water to each 60-lb. (27.2 kg) bag of QUIKRETE® Concrete or Crack Resistant Concrete Mix. Mix thoroughly until a plastic-like (moldable) consistency is reached. If additional water is required, add small amounts until the correct consistency is obtained. The final water content should be 2.5-4.5 qts. (2.4 – 4.3 L) for each 80 lb. (36.3 kg) bag, or 2-3.5 qts. (1.9 – 3.3 L) for each 60 lb. (27.2 kg) bag.

APPLICATION

Use a bucket or trowel to fill each mold cavity level with surface of mold. While concrete is still in mold, pat and smooth cavity surface with trowel. Remove mold promptly. After removing the mold, smooth all edges with a trowel until appearance is satisfactory. Dipping trowel in water may be helpful. Place the mold adjacent to the completed section and continue this process until your project is completed.

CURING

Concrete should be damp-cured for 5-7 days for the greatest strength or QUIKRETE® Acrylic Concrete Cure & Seal – Satin Finish #8730 can be applied once the concrete hardens, but is

DIVISION 3

Maintenance of Concrete
03 01 00



still damp. (Apply according to directions on the package). To outline/trim blocks, fill-in separations with QUIKRETE® Sand/Topping Mix after concrete has cured. Place dry Sand Mix in cracks and sweep in to desired level. Dampen the Sand Mix with a fine mist of water (do not over-wet). Let Sand/Topping Mix harden to finish the project.

Note: The addition of QUIKRETE® Liquid Cement Color will dramatically enhance any Walk Maker® project. Mix the liquid color with water before adding it to the dry concrete mix. A variety of surface textures may be obtained by experimenting with different finishing techniques; i.e. a metal trowel will make a smooth surface, a wooden trowel will make a rougher surface and a brushed surface will add texture and expose more aggregate.

WARRANTY

The QUIKRETE® Companies warrant this product to be of merchantable quality when used or applied in accordance with the instructions herein. The product is not warranted as suitable for any purpose or use other than the general purpose for which it is intended. Liability under this warranty is limited to the replacement of its product (as purchased) found to be defective, or at the shipping companies' option, to refund the purchase price. In the event of a claim under this warranty, notice must be given to The QUIKRETE® Companies in writing. This limited warranty is issued and accepted in lieu of all other express warranties and expressly excludes liability for consequential damages.

The QUIKRETE® Companies
One Securities Centre
3490 Piedmont Rd., NE, Suite 1300, Atlanta, GA 30305
(404) 634-9100 • Fax: (404) 842-1425