



## How-To-Use

# Sikacryl® Stucco Patch

## Ready-Mix Repair

### Materials:

- Safety glasses and gloves
- 1 quart tub of Sikacryl Stucco Patch
- Small trowel or flexible putty knife
- Wire brush
- Water & clean rag for clean up

### Procedure

1. Make sure that all surfaces are clean, sound, dry and free from dirt and loose particles.
2. For best results, use a wire brush to clean off any loose particles or excess dirt or dust.
3. Use a small trowel or flexible putty knife to apply product to stucco surface.
4. Areas greater than 1/4 inch deep may require two or more applications.
5. Allow repaired area to cure for at least 1 hour minimum, depending on temperature, humidity and depth of repair. Full cure will be achieved in 72 hours.
6. Prime area prior to painting.
7. Clean up all tools, spills, and excess material immediately with water and clean rag after use.