

INSTALLATION TOOLS NEEDED:

- Flat-head screwdriver
- Pocket knife or scissors
- Pliers
- Power Drill
- ¼" drill bit

INSTALLATION INSTRUCTIONS:

- Lower Attic Door.
- Cut off existing cord.
- Drill ¼" hole where string was mounted (if required)
- Insert the Fashion Pull-Ring through the ½" hole on the exterior side of the Attic Door. Hand-tighten the fastener and washer assembly. Use screwdriver and pliers to tighten set screw.
- Raise the door back in place by inserting the hook of the Attic Ease™ Reach Hook into the Fashion Pull Ring.
- Locate a convenient place to store the Attic-Ease™ Reach Hook.
 A hall closet is usually ideal. Place the Reach Hook in the stowing Position and mark where the Storage Hook should go.
- Hand turn the Storage Hook into position. Hang up your Attic Ease™ Reach Hook,