



Installation Instructions

FastStone+ is bonded with 3M PE Form Tape. It sticks fast and hard so accurate placement “the first time” is required because it will not come off easily and damage may occur to the surface it was applied to while trying to remove the FastStone+. Not recommended for exterior use.

Before applying to the surface, make sure that the surface it is being applied to is free of dust, dirt and oils. After peeling off the protective cover on the backing, be careful as to the placement of the product since the adhesion is immediate and permanent.

Fast and easy direct application on all flat, clean, oil and dust free surfaces. For decorative designs of all kinds, ideal for walls, ceilings, displays or for “DIY”. If used for direct application, it is recommended to use exact cut-to-size sheets.

Cutting:

FastStone can be cut with tin snips with the stone surface facing top or a circular saw with the stone surface facing down. To improve the quality of the cut, it is recommended to place a thin piece of plywood or MDF panel on top. To protect against flying debris, we highly recommend wearing eye protection.

Application:

Before applying FastStone+, it is recommended to acclimate the Stone-Veneer sheet and the work object for at least 24 hours to avoid potential damage due to tension and/or warping. FastStone+ is applied, it is almost impossible to remove or re-adjust the sheet from the object without damage. To apply the panels, it is recommended to start at the top corner and work your way down. It is a must to follow a straight line and even line. To press the sheets onto the surface, it is recommended to use a felt or rubber roller.