



Manufacturers Advanced Composite Materials, Automotive and Apparel
Specialty Fabrics, Bias Binding, Electrical Insulation,
Narrow Fabrics, P.V.C. Film, Construction, Survey & Safety Accessories

MUTUAL INDUSTRIES INC.

707 W. GRANGE STREET, PHILADELPHIA, PA 19120

800 523-0888

215 927-6000

FAX: 215 927-3388

CUSTOMER SERVICE LINE

SAFETY FENCE

Suggested Installation Instructions:

1. Place T-posts no more than 10 feet apart. (Note: Metal U-post or rebar are not recommended as supports for safety fences.)
2. Pull safety fence taut and secure to the posts with plastic fence ties (zip ties). Loop the ties through the available holes or “teeth” in the post to prevent the fence from sliding down the post. Place zip ties every 12 in vertically down fence post.
3. For additional longevity pull the safety fence taut and secure to the T-post. Use plastic fence ties (zip ties) to secure the slat and fence to the T-post at the top, middle and bottom of the fence. Loop the tie through the “tooth” at top and bottom of the post to prevent the safety fence sliding down the post.
4. For the greatest longevity of the safety fence, it can be suspended from a wire (plastic, metal, rope, etc.). This is in addition to the securing method explained in #3 above. This wire should be woven through the upper openings of the safety fence and through the holes in the posts. The wire should then be secured at both ends of the safety fence.
5. To connect fence sections, overlap two ends by at least 6 inches and weave a wood slat through the overlapped strands. Secure the joined area to the T-post.