



Glass Warehouse

Single Shower Panel Installation Guide (Fixed Panel)

BEFORE YOU START

The most fragile parts of tempered glass panels are the corners. Therefore, it is critical you have the rubber blocks in place so the glass never touches the tile surface you are installing onto. Please make sure the glass is always on blocks while out of the packaging prior/during install. We have provided some rubber blocks as part of the install kit but you can use wood, cardboard or other rubber products to protect against breakage.

Silicon is not provided as part of the install kit, this will need to be purchased separately. We recommend using clear, mold resistant silicon which be purchased at your local hardware store.

Glass Warehouse is here to assist you, so if you run into any troubles or have any queries don't hesitate to call us on: (214) 932-9116.

PART ONE – Install Fixed Panel

1. On the wall where the fixed panel is to be placed, mark a level vertical line on the wall with a level.
 - a. This line is where you will be attaching the 2 clamps to the wall.
 - i. **TIP:** We recommend using a pencil so this can be easily removed.
2. Mark the center point for the two clamps.
 - a. Top: measure 7¹/₄ inches from the floor along the vertical line.
 - b. Bottom: measure 7³/₄ inches from the floor along the vertical line.
 - c. The extra two clips are for the floor and should be placed approximately 2" from each edge.
3. Drill clamps to the wall / floor.
 - a. Drill holes using a 1/8" tile drill bit and insert the plugs provided.
 - b. Place clamp over hole and drill in screws to secure the clamp. Make sure these are tightly secured to wall.
4. Set the fixed panel in place.
 - a. Place the 1/16" rubber block provided inside the clamps on the floor, this is to prevent the glass touching the clamp where all the weight is. No blocks are required in the clamps on the wall. There are extra rubber blocks in case your floor is not level and you need to raise one end.
 - b. Carefully place the fixed panel on the rubber blocks and in floor clamps and slide the glass into the clamps on wall.
 - i. **IMPORTANT:** The most fragile parts of the glass panels are the corners. Therefore, it is critical you have the rubber blocks in place so the glass never touches the tile surface you are installing onto.
5. Ensure the fixed panel is level.
 - a. Use a spirit level to make sure the fixed panel is level and in line.
 - i. **TIP:** Use additional rubber blocks on either existing blocks to raise/drop the fixed panel if required.

PART TWO – Silicone Fixed Panel

1. Silicone the wall and floor surface of the fixed panel.
 - i. **TIP:** Spraying the silicone with soapy water AFTER applying the silicone and using a spatula of some kind to remove the silicone residue will give you a nice clean and professional finish.
2. Once you have completed the silicone this will take approx. 24 hours to set.