

Model AF505N Parts List

A = Standard Equipment


O = Circuit Diagram

Item#	Part#	Description	Q'ty	Unit
001	HY00000001	HEX.SOCKET HEAD BOLT M4X1	1	PC.
002	HY00000002	SLEEVE4	1	PC.
003	HY00000003	EXHAUST COVER	1	PC.
004	HY00000004	RUBBER WASHER 7	1	PC.
005	HY00000005	HEX.SOCKET HEAD BOLT M5X2	4	PC.
006	HY00000006	TOP CAP	1	PC.
007	HY00000007	TOP CAP GASKET	1	PC.
008	HY00000008	CUSHION V	1	PC.
009	HY00000009	COMPRESSION SPRING 7	1	PC.
010	HY00000010	O-RING 12	1	PC.
011	HY00000011	O-RING 33	1	PC.
012	HY00000012	HEAD VALVE	1	PC.
013	HY00000013	O-RING 29	1	PC.
014	HY00000014	CUSHION P	1	PC.
015	HY00000015	CYLINDER SEPARATER	1	PC.
016	HY00000016	O-RING 46	1	PC.
017	HY00000017	O-RING 24	1	PC.
018	HY00000018	DRIVER COMPLETE	1	PC.
019	HY00000019	CYLINDER	1	PC.
020	HY00000020	O-RING 36	2	PC.
021	HY00000021	O-RING 31	1	PC.
022	HY00000022	CUSHION F	1	PC.
025	HY00000023	FRONT SEAL	1	PC.
026	HY00000024	SPRING PIN 3-26	1	PC.
027	HY00000025	HOLDER	1	PC.
028	HY00000026	COMPRESSION SPRING 5	1	PC.
029	HY00000027	STOPPER	1	PC.
030	HY00000028	CONTACTARM COMPLETE	1	PC.
031	HY00000377	CONTACT TOP	1	
032	HY00000378	NOSE ADAPTER	1	
034	HY00000093	CAUTION LABEL	1	
035	HY00000033	RUBBER RING 8	1	PC.
036	HY00000034	TRIGGER VALVE GUIDE	1	PC.
037	HY00000035	COMPRESSION SPRING 4	1	PC.
038	HY00000036	TRIGGER VALVE STEM	1	PC.
039	HY00000037	O-RING 3	2	PC.
040	HY00000038	TRIGGER VALVE CASE	1	PC.
041	HY00000039	O-RING 11	1	PC.
042	HY00000040	COMPRESSION SPRING 10	1	PC.
043	HY00000041	IDLER	1	PC.
044	HY00000042	SPRING PIN 2.5-17	1	PC.
045	HY00000043	RUBBER RING 2	1	PC.
046	HY00000044	TRIGGER	1	PC.
047	HY00000045	PIN 3	1	PC.
048	HY00000046	PIN 2	2	PC.
050	HY00000047	DRIVER GUIDE	1	PC.
051	HY00000048	PLATE	1	PC.
052	HY00000049	HEX.SOCKET HEAD BOLT M5X2	2	PC.
053	HY00000050	DOOR	1	PC.
054	HY00000051	CAP	1	PC.

055	HY00000052	LEVER COMPLETE	1 PC.
056	HY00000053	SPRING PIN 2.5-16	1 PC.
057	HY00000054	SPRING PIN 2.5-18	1 PC.
058	HY00000055	SPRING PIN 1.5-18	1 PC.
059	HY00000056	HEX.SOCKET HEAD BOLT M4X1	4 PC.
061	HY00000057	PUSHER	1 PC.
062	HY00000058	PIN 7	2 PC.
063	HY00000059	COMPRESSION SPRING 6	2 PC.
064	HY00000060	MAGAZINE PLATE	1 PC.
065	HY00000061	SLIDE DOOR COVER	1 PC.
068	HY00000062	HOOK	1 PC.
069	HY00000063	PIN 3	1 PC.
070	HY00000064	STOP RING (EXT) E-2.5	1 PC.
071	HY00000065	TORSION SPRING	1 PC.
072	HY00000066	LOCK LEVER	1 PC.
073	HY00000067	CAUTION LABEL	1 PC.
074	HY00000069	CAUTION LABEL	1 PC.
075	HY00000070	WASHER	1 PC.
076	HY00000071	HEX.SOCKET HEAD BOLT M4X6	1 PC.
077	HY00000072	JOINT	1 PC.
078	HY00000073	HEX.LOCK NUT M5	1 PC.
079	HY00000074	HEX.SOCKET HEAD BOLT M4X8	2 PC.
080	HY00000075	HEX.SOCKET HEAD BOLT M5X3	1 PC.
082	HY00000076	INLET CAP	1 PC.
083	HY00000079	ONE TOUCH JOINT	1 PC.
084	HY00000083	TRIGGER COMPLETE (43 44 46)	1 PC.
	D10	INC. 43,44,46	
085	HY00000084	MAGAZING ASSY	1 PC.
	D10	INC. 73,74	
086	HY00000087	HOUSING COMPLETE	1 PC.
	D10	INC. 34	
087	HY00000020	O-RING 36	1 PC.
088	HY00000056	HEX.SOCKET HEAD BOLT M4X1	4 PC.
A01	HY00000090	PLASTIC CASE	1 PC.
A02	195246-2	SAFETY GOGGLE	1 PC.
A03	181434-7	OIL SUPPLY 30CC	1 PC.

Makita Air Compressor Part Breakdown - MODEL AC001

Item	Description	Part #	Qty	Item	Description	Part #	Qty
1	Cylinder head	WS0101017E	1	37	Drain cock	413008-E	1
2	Bolt/cylinder head	WS0353015E	4	38	Regulator	WS0410001E	1
3	Spring washer	WS0382002E	4	39	Quick coupler	447013-E	1
4	O-Ring	WS0333011E	1	40	Unloading elbow	WS0151009E	3
5	Round-head bolt	WS0353148E	2	41	Unloading tube	WS0240024E	1
6	In & Exhaust valve plate	WS0115004E	2	42	Unloading tube	WS0240044E	2
7	In six angle bolt	WS0356005E	1	43	Unloading elbow	151001-E	3
8	Crankcase	WS0301023E	1	44	Tank foot assembly	434002-E	4
9	Crankcase front cover	WS0304019E	1	45	Flat washer	WS0381021E	4
10	Round-head bolt	WS0353021	4	46	Valve kit	WS00VK001E	1
11	Crankcase cover gasket	WS00215014	1	47	Piston kit	WS00PK001E	1
12	Electric motor/Crankcase/Wiring harness	WS2519091E	1	48	Round-head bolt	WS00353063	2
13	run capacitor	WS0462020E	1				
14	Capacitor cover	WS0455020E	1				
15	Motor fan with screw	WS0431014E	1				
16	Motor cover	WS0432013E	1				
17	Flange cross bolt	WS0354006E	3				
18	Power cord	WS0452011E	1				
19	Plastic washer	WS0384003E	4				
20	Spring washer	WS0382003E	4				
21	Round-head bolt	WS0353024E	8				
22	Air tank	WS0401184E	1				
23	Control panel	WS0488048E	1				
24	Bolt for console	365003-E	6				
25	Pressure gauge	411029-E	2				
26	Pressure gauge bolt	WS0353001E	6				
27	Set nut	WS0371001E	6				
28	Pressure switch	WS0412006E	1				
29	Strain relief clip	WS0457005E	2				
30	Check valve	WS0409017E	1				
31	Unloading elbow	WS0152101E	1				
32	Unloading tube assembly (1/4")	WSS228038E	1				
33	Unloading tube assembly (1/4")	WS0228044E	1				
34	Unloading elbow	151002-E	1				
35	rubber handle	WS0435001E	1				
36	Safety valve	WS0407009E	1				



PB-EN-MKTA-140328
www.makita.com