




ASSEMBLY INSTRUCTIONS



Meadow Media Console | SL-MCON-5

IMPORTANT - PLEASE READ THESE INSTRUCTIONS FULLY BEFORE STARTING ASSEMBLY

For assistance with assembly or customer service, call 1-877-924-2090 (English)
Monday-Friday, 8 a.m. to 5 p.m. Mountain Time, North America. Email:
customerservice@rstbrands.com or visit our website at www.rstbrands.com



SAFETY AND CARE ADVICE

IMPORTANT - PLEASE READ THESE INSTRUCTIONS FULLY BEFORE STARTING ASSEMBLY

HELPFUL HINTS

- Please read through the assembly instructions thoroughly before you begin.
- Check all fittings and panels against the parts list to ensure that you have everything before you start. In the unlikely event that any parts are missing, please contact your retailer immediately.
- The use of power tools is NOT advised, this could damage your product and cause over tightening to occur.
- Assemble the item as close to its final position (in the same room) as possible.
- Make sure you have enough space to layout the parts before starting.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Check you have all the components and tools listed on the next page.

CARE AND MAINTENANCE


- Periodically check there are no loose screws or fittings.
- For cleaning please use a clean damp cloth or duster. Use of abrasive or chemical cleaners will most likely scratch or damage the surface of your product.
- The surface of this item is not heat resistant. Please use a mat under hot, cold or wet items to prevent marking.

SAFETY

- Keep children and animals away from the work area, small parts could choke if swallowed.
- Do not stand on the product, this could cause damage.
- Where applicable ensure the unit is fixed to a wall.
- Dispose of all packaging carefully and responsibly.

COMPONENTS - PARTS





















PLEASE CHECK YOU HAVE ALL THE PARTS LISTED BELOW



HARDWARE LIST



PLEASE CHECK YOU HAVE ALL THE FITTINGS LISTED BELOW

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A		Cam Bolt	40 pcs
B		Cam Lock	40 pcs
C		Dowel Ø8 x 30mm	36 pcs
D		Unitar M6.3 x 50mm	10 pcs
E		73 x 27 x 20mm	4 pcs
F		M10 x 16mm	8 pcs
G		Barn Door Roller	4 pcs
H		Slider	4 pcs
I		Floor Glide	6 pcs
J		Plastic Wedge	8 pcs
K		Screw M3.1 x 20mm	8 pcs
L		Shelf Pin	24 pcs
M		Handle	2 pcs
N		Bolt M4 x 22mm	4 pcs
O		Screw M3.5 x 15mm	8 pcs
P		Hex Key M4	1 pcs
Q		Screw M6 x 12mm	8 pcs
R		Flat Washer M6 x 19mm	8 pcs
S		Safety Strap 200mm	2 pcs
T		Screw M3.5 x 25mm	2 pcs


ASSEMBLY INSTRUCTIONS

Step 1



C x 12

Step 2






A x 18

Step 3





B x 6



Step 4




C x 8



Step 5




D x 10



Step 6





A x 4



Step 7





B x 4



Step 8






C x 8



Step 9





B x 12




Step 10



1 x 6





Step 11



Step 12





L x 24




Step 13





A x 2



Step 14





C x 4





Step 15






B x 2




Step 16






	
A x 4	C x 4




Step 17





B x 4









Step 18




Step 19






				
G x 4	H x 4	O x 8	Q x 8	R x 8





Step 20



	
M x 2	N x 4





Step 21



Step 22








A x 12




Step 23







B x 12




Step 24







	
E x 4	F x 8





Step 25





	
J x 8	K x 8




Step 26

	
S x 2	T x 2



Step 27



WARRANTY POLICY

Welcome to the RST Family

Here at RST Brands™ we are committed to your satisfaction by offering you a competitive warranty to ensure all our products are free from defects, in material and workmanship, to the original purchaser for a period of one year from the date of your purchase.

How It Works

We are happy to furnish a replacement at no cost to you in the case we determine a component to be defective. While our warranty applies to conditions of normal use, it does not apply to defects or damage resulting from intentional or accidental damage, outdoor use, negligence, or unreasonable use.

Here to Help

Please immediately report any defect to RST by calling (877) 924-2090 or send an email to customerservice@rstbrands.com. Have your receipt and order number handy for our team of customer service professionals that will be eager to assist you.

**For assistance with assembly or customer service, call 1-877-924-2090 (English)
Monday-Friday, 8a.m. to 5 p.m. Mountain Time, North America. Email:
customerservice@rstbrands.com or visit our website at www.rstbrands.com**

