

# Pre-Assembly

## PLANNING ASSEMBLY

Identify all parts packed in the carton against the parts list. Remove all protective materials. Place parts on a non-abrasive surface to avoid scratching. If you are missing any parts or are unsure how to proceed with the assembly, call our Customer Service Team at 1-800-986-3460. Do not attempt assembly if any parts are missing or damaged.


Two people may be required to assemble the swivel rocker.

Damage to welds or frames resulting from over tightened bolts or improper assembly is not covered under our warranty. Please read all instructions carefully before assembly. If you have any questions regarding your assembly, call our Customer Service Team at 1-800-986-3460.

## HARDWARE INCLUDED



NOTE: Hardware not shown to actual size.



Part	Description	Order Part #	Quantity
AA	5/16 in. x 40 mm Bolt	HW0295	4
BB	Ø8.0 x 2.3 mm Spring Washer	HW0003	4
CC	Metal plate	HW0686	2
DD	5/16 in. Nut	HW0015	4
EE	Bolt Cover	HW0028	4
FF	Ø8.5 x 1.5 mm Washer	HW0005	4
GG	Hex Wrench-1	HW0008	1
HH	Hex Wrench-2	HW0007	1
II	Footrest Cover (Preassembled)	G0155	4
JJ	Foot Cap (Preassembled)	FC0839	4