


BUOY BALL WITH TRAPEZE (04-0012)

- 1: ATTACH ONE SPRING CLIP TO EACH S-HOOK ON THE TRAPEZE BAR.
- 2: ATTACH CHAIN ENDS TO SPRING CLIPS.
- 3: ADJUST HEIGHT AS NEEDED.



FOR RESIDENTIAL USE ONLY
FOR CHILDREN AGES 3-11

SEE INFLATION INSTRUCTIONS ON BACK OF THIS PAGE.

INFLATION INSTRUCTIONS

Air needles are used to inflate basketballs, soccer balls, footballs, kick balls and our punching ball/buoy ball on your play set. An air needle is not included. You may purchase one of these air needles at any department or sporting goods store.




Air Needle

- 1) Moisten the air needle with water.
- 2) Place the locking end of your hand operated air pump or electric air pump onto the threaded end of the air needle and lock it into place.
- 3) Place the air needle into the small valve in the Punching Ball or Buoy Ball.
- 4) Inflate the Punching Ball/Buoy Ball until it is firm like a kick ball. Do not over-inflate. A pressure of 3 to 6 p.s.i. should be sufficient.
- 5) Turn off the electric air pump if you are using one. Remove the air needle from the Punching Ball/Buoy Ball. Remove the locking end of the air pump from the air needle.
- 6) Store the air needle in a safe place away from young children as this could pose a choking hazard.
- 7) After a period of time if the Punching Ball/Buoy Ball loses air pressure, re-inflate it as required.

Trapeze Bar 21" (04-0005)

1. The Trapeze Bar comes with two zinc plated chains. Chains are approximately 3 feet long. The Trapeze Bar is 21" in length and is 1" diameter. The Trapeze Bar is coated with plastisol, a plastic coating. A steel ring is welded onto each end of the Trapeze Bar on the top. Each steel ring is connected to a chain with an "S"-hook. A plastic handle is attached to each "S"-hook with another "S"-hook.
2. There are many different ways to connect the chains to the swing hangers that exist on your swing set or custom swing. Always follow the manufacturer's directions on how to attach the swing to the swing hangers.
3. Safety comes first when swinging. Always obey the safety rules when swinging and when walking around a swing set. We have included a Safety Tips guide on page 2.
4. Trapeze Bar Weight Limit: 125 lbs



FOR RESIDENTIAL USE ONLY
FOR CHILDREN AGES 3-11

SAFETY TIPS FOR SWINGS

- On-site adult supervision is required.
- Teach children not to walk close to, in front of, behind, or between **moving swings** or other moving playground equipment.
- Teach children to sit in and never stand on swings. (Exception to this rule is a product called "Stand -N- Swing")
- Teach children not to twist the chains and ropes and not to loop them over the swing beam, since this may reduce the strength of the chain or rope.
- Teach children not to jump from swings that are in motion.
- Teach children not to push empty seats. The seat may hit them and cause injury.
- Teach children to sit in the center of swings with their full weight on the seats.
- Teach children not to use the equipment in a manner other than intended.
- Parents should have the children dress appropriately with well-fitting shoes. Loose clothing such as scarves and ponchos should not be worn. Always take off, tie up or tuck in cords and drawstrings on children's clothing. These things can get caught on playground equipment and strangle a child.
- Teach children not to climb when the equipment is wet.
- Teach children not to attach items to the playground equipment that are not specifically designed for use with the equipment, such as, but not limited to, jump ropes, clothesline, pet leashes, cables and chain as they may cause a strangulation hazard.
- Teach children to never wrap their legs around swing chain.
- Teach children to never slide down the swing chain.
- Protective surfacing under swings is recommended. "To and Fro" swings should have a fall zone extending a minimum of 6' from the outer edge of the support structure on each side. The "fall zone" in front and back of the swing should extend out a minimum distance of twice the height of the swing as measured from the ground to the top of the swing support structure. Swings should have a minimum of 8 inches between them. (ASTM F-1148-09) The bottom of a swing should not be less than 8 inches above the protective surfacing material. (ASTM F-1148-09) Home Playground Safety Specification ASTM F-1148-09 may be purchased online. A guide for Public Playground Safety from the U.S. Consumer Product Safety Commission may be downloaded at: www.cpsc.gov/cpscpub/pubs/325.pdf
- A fall zone for a "tire swing" capable of unlimited lateral motion will be equal to a minimum horizontal distance of $Y + 72$ in. in all directions from the pivot point of the swing. Y equals the vertical distance between the pivot point and the top of the tire swing. Protective surfacing is recommended in the fall zone for tire swings.

If any of the following conditions are noted they should be removed, corrected or repaired immediately to prevent injuries:

- Hardware that is loose, or worn, or those that have protrusions or projections.
- Scattered debris, litter, rocks or tree roots.
- Missing or damaged equipment components, such as swing seats.
- Remove plastic swing seats and take indoors (or do not use) when the temperature drops below 32° F.
- Oil all metallic moving parts monthly during the usage period.
- Check swing seats, ropes, cables and chains monthly during usage season for evidence of deterioration.

Replacement should be made of any swing seat that has developed cracks in the plastic seats or has exposed metal in the edges of the swing seat. If there are already exposed metal inserts on the edge of the seat, immediately remove the seat and chains to prevent serious injury. Ropes, cables and chains should be removed and replaced if excessive wear is found.