

Use and Care Instruction

Store outdoor furniture indoors or cover well when not in use.

To maintain the finish, clean the surface by using a soft cloth. Do not use a metal brush.

Do not use sharp object to knock or scratch the surface.