



#### Use and Care

To clean, wipe off dust and dirt with a damp cloth and mild soap

For outdoor use, to extend the life of your rocker, store in a covered area or porch.