



FRIGIDAIRE

Factory Parts Catalog

Product No.	FFGW2415QSA
Series	24" gas
Color	stainless
Market	North America
Owner's Guide	A00327401
Installation Instructions	807017901
Service Data Sheet	A04967801

Frigidaire


P.O. BOX 8020
CHARLOTTE, NC 28262

Publication No.
5995672606
16/01/27
(EN/SERVICE/ECL)
377

24" SINGLE GAS WALL OVEN

Model No.
FFGW2415Q

CONTROL PANEL




C79040292410

CONTROL PANEL

POS. NO	PART NO.	DESCRIPTION
2	139029900	Cover, wrapper, top
3	139030902	Cover, oven top, front
12 #	316448700	Switch, rocker, black, oven light
17	5304498101	Insualtion, control panel
18	808181801	Insulation, control panel, (2)
19	5304504307	Control Panel, assembly, black/stainless
20 #	316455456	Clock/Timer, electronic, ES100/105
20A	318213813	Overlay, clock, black, ES100
21	5304504256	Shield, control, upper
22	808752302	Trim, vent cover, black, top
24	139099502	Trim, vent, black, control panel
*	316021105	Screw, hex head cup pt, 8-18 x 0.375, black
*	316021110	Screw, 8-18 x 0.5, black
*	5304504225	Screw, Plastite, 48 #7-18x12.7, (4)

BURNER




BR79040292410

BURNER

POS. NO	PART NO.	DESCRIPTION
14 #	316416706	Regulator, pressure
15	5304498069	Bracket, regulator mtg.
16 #	807181201	Tube, regulator, to valve
17 #	807192701	Valve, safety
18 #	5304502520	Burner, bake
20	139076600	Baffle, oven burner
20*	316260800	Screw-shoulder, w/shoulder, #8-18 x 1/2"
20*	318165800	Spacer, glass, foam
21	5303013272	Nut, hex head sems
26 #	318177710	Ignitor, oven burner
26*	316418901	Screw, trilobe, 10-32 x 5/16", black
* #	5304504261	Harness, ignitor jumper
*	316021105	Screw, hex head cup pt, 8-18 x 0.375, black

BODY




BFFGW2415QBA

BODY

POS. NO	PART NO.	DESCRIPTION
1	139029600	Panel, main back
2	139028801	Shield, insulation, top
3	807193201	Panel, back cover
6	139012300	Rack, oven, (2)
8	139076701	Cover, oven bottom
11	807108501	Seal, oven door
12 #	316445501	Switch, oven light, door frame
12A	5304504232	Shield, door switch
12A*	809136201	Screw, truss head, #8-32 x 3/8"
15 #	139009000	Lamp Assembly, round, halogen, w/lens, w/bulb
15*#	318946500	BULB, halogen, G9, 25W, 120V
16	807246201	Flue Adaptor, assembly
17	807245701	Flue Assembly, Y channel
18	5304498078	Shield, power connector
19	5304498109	Shield, vent
23	139004500	Cover, broil opening
25	808054701	Shield, heat, lower
26	139080700	Panel, drawer side, (2)
29	316517600	Bumper, front, main
33	808054101	Frame, service panel, valve
34	808054601	Panel, valve mounting
35	807180901	Gasket, flue adaptor
36	5304504262	Gasket, flue base
37 #	318562500	Sensor, oven temp probe
39 #	807108201	Cord, electric power
39*	316001003	Screw, ground wire
39*	318579001	Bracket, wire
40	5304498071	Box, burner
41	807844602	Bracket, body, middle
42	5304504567	Panel, lower
43	3131732	Screw, 8-18 x 1.438, oven bottom
56	139081902	Trim, side, black, RH
56A	139081802	Trim, side, black, LH
58	808553101	Insulation, wrapper, oven
58A	807780401	Insulation, wrapper
58B	807779801	Insulation, flue, (2)
58C	139028500	Insulation, cavity, rear
59	807780501	Shield, flue insulation, bottom
60	807780601	Shield, Intermediate, top
70	139000600	Shield, insulation, sides, (2)
71	139029000	Shield, rear wire
80	139021101	Bracket, support, chassis/fan
80*	807597603	Screw, self tapping, 8-18 x 11/32, (4)
86	318561100	Receptacle, hinge, (2)
86*	316418900	Screw, sims lp, #8-32 x 5/16", black
90	139905004	Trim, bottom, stainless
90*	318165800	Spacer, glass, foam
99	318284201	Panel, adjustable, side, (2)
185	318531800	Spacer, oven shield, (2)
185*	5303289910	Screw, truss sqdr, 8A x 1"
200	5304498076	Frame, Compartment, (2)
201	5304498099	Bracket, Compartment, frame
264	139086101	Trim, vent, black, upper
* #	5304498103	Harness, wiring, main
*	316021105	Screw, hex head cup pt, 8-18 x 0.375, black
*	316021109	Screw, 8-18 x 0.5, chrome
*	316021110	Screw, 8-18 x 0.5, black
*	5304470882	Screw, anti-tip, 8 - 5/8, black, (2)

DOOR/DRAWER




DDFGW2415QSA

DOOR/DRAWER

POS. NO	PART NO.	DESCRIPTION
2	139076801	Liner, broiler drawer
2*	316021110	Screw, 8-18 x 0.5, black
2A	807192402	Panel, inner drawer, black, front
2B	807193402	Frame, drawer liner
3A	139014401	Trim, oven door, black, side, (2), vented
3B	807192602	Cover, door, rear, (2)
4	807278104	Panel, drawer, stainless, outer
6	139083101	Shield, oven door, wool
7	807193502	Insulation, door, side
7A	807193501	Insulation, door, top/bottom
8	139085800	Glass, door, inner, (2), HRC2
9	139014509	Liner, door
10	5304414648	Screw, handle mtg.
11	318126200	Pan, broiler
12	318126300	Insert, broiler pan
13	5304504224	Door Assembly, outer, glass/steel, black/stainless, w/badge
16	139085900	Glass, door, airwash
17	139085700	Spacer, door glass, (2)
23	316575916	Hinge, oven door, white
23*	316418900	Screw, sims lp, #8-32 x 5/16", black
30	808664401	Hinge, drawer, RH
30A	808664402	Hinge, drawer, LH
*	316089500	Screw, 10-16 x .486
31	808721501	Spring, broiler drawer, (2)
35	5304504568	Drawer Assembly, carriage, w/rollers
37	3203722	Rail, drawer, RH
37A	3203723	Rail, drawer, LH
*	5303013272	Nut, hex head sems
39	5304498070	Handle, door, stainless
40	318242702	Bracket, glass holder, door, (2)
41	318370602	Bracket, glass panel, (2)
42	318382301	Bracket, glass retainer, (4)
56	809136201	Screw, truss head, #8-32 x 3/8"
56A	5303300195	Screw, 10-32 x 0.375, (2)
60	5303292012	Screw, wafer HD, #10-24 x 5/8, (2)
64	318165800	Spacer, glass, foam
135	318147413	Bumper, body side, (4)

WIRING DIAGRAM



CAUTION:
DISCONNECT POWER BEFORE SERVICING UNIT.
LABEL ALL WIRES PRIOR TO DISCONNECTION WHEN SERVICING CONTROLS.
WIRING ERRORS CAN CAUSE IMPROPER AND DANGEROUS OPERATION.
VERIFY PROPER OPERATION AFTER SERVICING.

ATTENTION:
DÉBRANCHEZ L'APPAREIL AVANT DE PROCÉDER À LA RÉPARATION.
IDENTIFIEZ TOUS LES FILS AVANT DE LES DÉBRANCHER LORSQUE VOUS PROCÉDEZ À UNE RÉPARATION.
UNE ERREUR DE FILAGE PEUT CAUSER UN FONCTIONNEMENT INADÉQUAT ET/OU UNE SITUATION DANGEREUSE.
VÉRIFIEZ QUE L'APPAREIL FONCTIONNE CORRECTEMENT APRÈS LA RÉPARATION.

COLOR CODE
CODE DE COULEURS
W = WHITE/BLANC
Y = YELLOW/JAUNE
T = TAN/OCRE
V = VIOLET
BK=BLACK/NOIR