



Removes the toughest hard water spots and film from dishes and glassware

Hard water may be the reason your clean dishes have a lackluster appearance. Using Lemi Shine® Booster in every wash solves this problem. Lemi Shine® Dish Detergent Booster is super concentrated, phosphate-free and septic system-friendly.

POWERED BY 100% CITRIC EXTRACTS

Non-toxic, biodegradable, phosphate free, septic system friendly Combined with your dishwasher detergent, Lemi Shine® Booster removes spots, stains, and film during the main wash cycle

No more rewashing dishes saving time, energy and water









Use Lemi Shine® Booster In Every Wash

Read complete caution before using.

For optimal results, first clean your machine with Lemi Shine[®] Machine Cleaner to remove years of hard water buildup, spots, stains and film. Use as directed.

- 1. Rinse and load dishes & glassware
- 2. Fill main wash receptacle with Lemi Shine® *
- 3. Fill pre-wash receptacle with your favorite detergent** (If only one receptacle is present, fill half with Lemi Shine® and half with detergent or place detergent in bottom of dishwasher)
- 4. Start dishwasher as normal

** For best results, use with Lemi Shine® Detergent *Depending on water hardness

Lemi Shine® Booster Ingredients Ingredients: citric acid and citrus oils



Caution

Keep out of reach of children. Check manufacturers' suggested cleaning instructions on all dishwasher safe items.

Not recommended for sliver, painted glassware, painted mugs, aluminum, fine china or any enamel coated cutlery or cookware.

Do not use with non stick coated cookware or removable stovetop components.

Do not mix with liquid bleach. If eye contact occurs, flush eyes with water. If swallowed, drink plenty of water to dilute. If any irritation develops, contact your Physician.



A bona fide Clean Freak is standing by to answer your questions.

We pride ourselves on phenomenal customer service. Write or call.. we are here to help!

US Phone Support Monday - Friday 8:00am - 5:00pm CST 888.336.2582 Canada Phone Support Monday - Friday 8:00am - 5:00pm CST 432.687.2582