

# **USKY.** Instruction Sheet

#### **WARNING**





This warranty excludes incidental/inconsequential damages and failures due to misuse, abuse, normal wear and tear and dulling of the blade(s).

If you have any question concerning this product:

- Contact your local Homedepot Store.
- Contact 1-888-HD-HUSKY.

## **Specifications**

- · Automatically tightens as it turns
- Provides even/smooth cuts
- For copper tubes 1/2 in.
- Change blade with SKU 1000002520 2-piece replacement blade set
- 1/2 in. maximum NPS capacity, 1/2 in. minimum NPS capacity
- 5/8 in. maximum O.D. pipe size capacity, 5/8 in. minimum O.D. pipe size capacity

#### **Product Overview**

Husky's 1/2 in. Auto Tube Cutter makes cutting tubes easy and intuitive. The spring-loaded cutter wheel tightens while turning to maintain constant pressure, resulting in cleaner cuts. The hardened steel wheel and lightweight plastic body makes cutting smoother.

## **Operating Instructions**

- 1. Place tube between guide roller and cutting wheel.
- 2. Rotate auto cutter to cut.

