

TROUBLESHOOTING:

	Possible Cause	Corrective Action
Bulb will not light.	1. Bulb is burned out.	1. Replace light bulb.
	2. Power is off.	2. Make sure power supply is on.
	3. Faulty wire connection.	3. Check wiring.
Fuse blows or circuit breaker trips when light is turned on.	Crossed wires or power wire is grounding out.	Check wire connections.

PRODUCT MAINTENANCE:

1. To clean the outside of the fixture, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the glass and surface of the fixture.
2. To clean the inside of the fixture, first disconnect power to the fixture by turning off the circuit breaker or by removing the fuse at the fuse box. Next, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the inside glass and interior surface of the fixture.
3. Do not use any cleaners with chemicals, solvents or harsh abrasives. Use only a dry soft cloth to dust or wipe carefully.


LIMITED WARRANTY

The manufacturer warrants this lighting fixture to be free from defects in materials and workmanship for a period of one (1) years from date of purchase. This warranty applies only to the original consumer purchaser and only to products used in normal use and service. If this product is found to be defective, the manufacturer's only obligation, and your exclusive remedy, is the repair or replacement of the product at the manufacturer's discretion, provided that the product has not been damaged through misuse, abuse, accident, modifications, alterations, neglect or mishandling. This warranty shall not apply to any product that is found to have been improperly installed, set-up, or used in any way not in accordance with the instructions supplied with the product. This warranty shall not apply to a failure of the product as a result of an accident, misuse, abuse, negligence, alteration, or faulty installation, or any other failure not relating to faulty material or workmanship. This warranty shall not apply to the finish on any portion of the product, such as surface and/or weathering, as this is considered normal wear and tear. **The manufacturer does not warrant and specially disclaims any warranty, whether express or implied, of fitness for a particular purpose, other than the warranty contained herein. The manufacturer specifically disclaims any liability and shall not be liable for any consequential or incidental loss or damage, including but not limited to any labor / expense costs involved in the replacement or repair of said product.**



INSTRUCTION MANUAL Interior Decorative Lighting

Home Depot SKU (236-708) UPC (773546205375)



Thank you for purchasing this Hampton Bay interior decorative lighting. This product has been manufactured with the highest standards of safety and quality.

FEATURES:

An Antique Brass finish and nautical design makes this expressive pendant a welcome addition to the home.

Pendant can be installed at normal ceiling heights or over high ceilings using one to four standard 12" metal rods (included).

A White Frosted glass Diffuser creates a brilliant balanced ambient glow

QUESTIONS, PROBLEMS, MISSING PARTS:

Before returning to your local Home Depot, please call our Customer Service Team at 1-877-527-0313 or visit www.homedepot.com. Please reference your SKU# (236-708) or UPC# (773546205375)

CAUTION:

1. Before starting installation of this fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box.
2. CONSULT A QUALIFIED ELECTRICIAN IF YOU HAVE ANY ELECTRICAL QUESTIONS.
3. If you have any non-electrical questions about this fixture, please contact our Customer Service Team at 1-877-527-0313 or visit www.homedepot.com. Please reference your SKU# (236-708) or UPC# (773546205375)
4. Keep your receipt and these Instructions for Proof of Purchase.

TOOLS REQUIRED FOR ASSEMBLY & INSTALLATION (not included):



Light Bulb
(60 watt maximum)




Safety goggles



Wire Cutters



Wire Strippers



Flathead
Screwdriver



Phillips
Screwdriver



Electrical Tape


ADDITIONAL PARTS:



1. Hex Nut (x1)



2. Star Washer




3. Canopy




4. Finishing Nut
(x2)



5. Retaining Screw



7. Shade



8. Socket Ring (x1)



9. Diffuser (x1)




10. Finishing Screw

ASSEMBLY INSTRUCTIONS:

1. Carefully unpack the fixture. Lay out all parts on a clean surface.
2. Screw-in tightly and attach the 12" Rod (part of Fixture Body, # 6), followed by the End-piece (part of Fixture Body, # 6) to the Fixture Body, # 6.
3. Tighten the Retaining Screw (# 5) to hold the End-piece (part of Fixture Body, # 6) to the top-most 12" Rod (part of Fixture Body, # 6).
4. Draw the wires (including the grounding wire) through the Canopy (# 3)
5. Locate the Shade (# 7) and attach it firmly in place using the Socket Ring (# 8).
6. Once the fixture is installed in place, install one 60 Watt (maximum, not included) into the Socket (part of Fixture Body, # 6).
7. Locate the Diffuser (# 9) in place and attach firmly using Finishing Screws (# 10).

ASSEMBLY:



PARTS INCLUDED FOR INSTALLATION (parts are not to scale):



1 ea Canopy (#3)



2ea Outlet Box
Screws (#12)



1ea Ground
Screw
(#13)



2 ea Mounting
Screw (#14)



1ea Cross Bar
(#15)



3ea Wire
Connectors (#16)

INSTALLATION INSTRUCTIONS:

1. Attach the Mounting Screws (# 14) to the Universal Cross Bar (# 15)
2. Mount the Cross Bar (# 15) to the Outlet Box (# 11) using the two Outlet Box Screws (# 12) provided, with the Grounding Screw (# 13) facing downwards.
3. Connect the white wire from the fixture to the white wire from the Outlet Box (# 11) using one Wire Connector (# 16) and reinforce this connection by wrapping Electrical Tape around this junction.
4. Repeat Step 3 above for the black wires coming from the fixture and the Outlet Box (# 11).
5. Connect the copper grounding wire from the fixture and from the Outlet Box (# 11) to the Grounding Screw (# 13) on the Universal Cross Bar (# 15). Note: If you have questions that are electrical in nature, consult your local electrical code or a qualified electrician for approved grounding methods.
6. Push all electrical wires and connections well into the Outlet Box (# 11), ensuring that the wires and connections are not damaged.
7. Push the Canopy (# 3) to the ceiling aligning its holes with the Mounting Screws (#14) and hold it in place flush with the ceiling using the Finishing Nuts (# 4).
8. Installation is complete, after completing Steps 6 and 7 of the Assembly Instructions as shown on Page 4.
9. Turn ON the power at the circuit breaker of fuse box.
10. Turn the light switch ON, to activate the fixture.

INSTALLATION

